



Technical Service Bulletin

TB14	Affected Models:	Ford F-250/350 Trucks 1983-88
	Problem:	High Pedal Effort
	Solution:	Periodic Release Bearing Lubrication
	Ref. Bulletin:	Ford Article 88-18-10

Ford recommends lubricating the release bearing at every oil change interval. Apply the lubricant as follows:

1. Remove the clutch hydraulic slave cylinder from the transmission bell housing.
2. Remove the clutch release lever and rubber shield from the bell housing.
3. Using a long screwdriver, apply a multi-purpose long-life lubricant to the bearing retainer through the bell housing opening.
4. Slide the release bearing on the retainer to spread the grease.

Be sure *not* to apply an excessive amount of grease in order to avoid contaminating the disc's friction material. Use only an approved lubricant; do not apply materials such as anti-seize.